



RUNNING BOARD

APPLICATION GUIDE

	SS Illuma Steps W/ Amber Lens	SS Illuma Steps W/ Clear Lens	Black Illuma Steps W/ Amber Lens	Black Illuma Steps W/ Clear Lens	Running Boards SS W/out Lights	Running Boards Blk W/Out Lights	Installation Kit
Chevrolet / GMC							
01-12 HD, 04-12 1500/2500/3500 Reg Cab	H022114	H022115	H022116	H022117			H015009
01-12 HD, 04-12 1500/2500/3500 Ext Cab	H022106	H022107	H022108	H022109	H022006	H022008	H015013
01-12 HD, 04-12 1500/2500/3500 Crew Cab	H022102	H022103	H022104	H022105	H022002	H022004	H015006
11-12 Chevy Diesel w/ Urea Tank Crew Cab	H022102	H022103	H022104	H022105	H022002	H022004	H015007 *
Dodge							
09-12 Ram 1500 Crew Cab	H022102	H022103	H022104	H022105	H022002	H022004	H015005
10-12 Ram 2500/3500 Crew Cab	H022102	H022103	H022104	H022105	H022002	H022004	H015005
10-12 Ram 2500/3500 Mega Cab	H022110	H022111	H022112	H022113	H022010	H022012	H015005
Ford							
04-12 F-150 Super Cab	H022106	H022107	H022108	H022109	H022006	H022008	H015001
04-12 F-150 Super Crew Cab	H022102	H022103	H022104	H022105	H022002	H022004	H015001
99-12 F-250/350/450 Reg Cab	H022114	H022115	H022116	H022117			H015010
99-12 F-250/350/450 Super Cab	H022106	H022107	H022108	H022109	H022006	H022008	H015010
99-12 F-250 Super Duty Crew Cab	H022102	H022103	H022104	H022105	H022002	H022004	H015002
Nissan							
04-11 Titan Crew Cab	H022102	H022103	H022104	H022105	H022002	H022004	H015004
05-11 Frontier Crew Cab	H022106	H022107	H022108	H022109	H022006	H022008	H015003
Toyota							
07-11 Tundra Crew Max	H022110	H022111	H022112	H022113	H022010	H022012	H015008 *
* In Development							